








Move/2500 – 信用卡交易指南







Move/2500 - User Guide for Credit Card Transaction




















開機 Turn On	於主畫面按 Press  ENTER	關機 Turn Off	於主畫面按 Press  + 
----------------------	---	-----------------------	--

信用卡消費 Credit Card Sale	於主畫面輸入金額 Enter Amount →  → 輸入小帳金額(如有) Enter TIPS amount (if yes) →  →	刷卡/插卡/拍卡 Swipe/Insert/Tap Card → 按  確認 ENTER 確定卡資料 to confirm card info. → 交易完成, 終端機打印單據 Transaction is completed, terminal print out receipt
----------------------------------	---	--

信用卡撤銷 Credit Card Void	於主畫面按  → 選擇“撤銷” Select “VOID” → 輸入撤銷密碼 Enter void password →  →	輸入發票號碼 Enter invoice number →  → 核對撤銷金額 Comfirm void amount →  → 交易完成, 終端機打印單據 Transaction is completed, terminal print out receipt
----------------------------------	---	---

小帳調整(如有) TIPS Adjustment (IF YES)	於主畫面按  → 選擇“小帳調整” Select “TIPS ADJUST” → 輸入密碼 Enter password →  →	選擇“發票號碼” Select “INVOICE NUMBER” → 輸入發票號碼 Enter invoice number →  → 按  確認 ENTER 確定交易 to confirm transaction →	輸入小帳金額 Enter TIPS amount →  → 按  確認 ENTER 確定小帳金額 to confirm tips amount → 交易完成, 終端機打印單據 Transaction is completed, terminal print out receipt
---	---	--	--

結算 Settlement	於主畫面按  → 輸入結算密碼 Enter settlement password → 選擇主機 Select host → 按  確認 ENTER 確定結算 to confirm settlement	結算完成, 終端機打印單據 Settlement completed, terminal print out receipt
-------------------------	---	---

重印 Reprint	1 於主畫面按  → 按  直至可以選擇“商戶功能” until “MERCHANT” could be selected →  →	按  選擇“2-重印” to select “2-REPRINT” → 按  選擇“1-最後交易” to select “1-LAST TRANSACTION” → 終端機打印單據 Terminal print out receipt
1.最後交易 LAST TRANSACTION 2.任何交易 ANY TRANSACTION	2 於主畫面按  → 按  直至可以選擇“商戶功能” until “MERCHANT” could be selected →  →	按  選擇“2-重印” to select “2-REPRINT” → 按  選擇“2-任何交易” to select “2-ANY TRANSACTION” →
3.最後結算 LAST SETTLEMENT	3 於主畫面按  → 按  直至可以選擇“商戶功能” until “MERCHANT” could be selected →  →	按  選擇“2-重印” to select “2-REPRINT” → 按  選擇“3-最後結算” to select “3-LAST SETTLEMENT” → 終端機打印單據 Terminal print out receipt